



**FIG. 1**

START

200

210 DETERMINE CPU UTILIZATION THRESHOLD CPUT

220 SET CPU UTILIZATION THRESHOLD CPUT

230 STORE CPU UTILIZATION THRESHOLD CPUT IN  
NVRAM

240 WAIT FOR INCOMING TELEPHONE CALL

250 NEW CALL RECEIVED?

NO

YES

260 DETERMINE PRESENT CPU UTILIZATION  
VALUE CPUP

270 COMPARE CPUP < CPUT

YES

NO

280 NORMAL CALL  
PROCESSING

SIGNAL CALL  
REFUSAL

FIG. 2